

Quick Start Guide

Turning ON

Hold down the button labelled 'Power' for 1-2 seconds then release it. The RF600 should now be ON.

Turning OFF

Hold down the button labelled 'Power' for about 3 seconds then release it. The RF600 should now be OFF. You should turn off the unit at the end of each day.

Auto OFF

The RF600 may automatically turn itself off if unused for more than 2 hours. Should this occur, simply turn the unit ON again.

Scanning the Badge

1. Hold the reader within 3 inches from the center of the badge as shown.
2. Press one of the large blue buttons.
3. When the reader has decoded the badge information you will hear 3 short beeps and the unit will display the information on screen.
4. Should there be any problem decoding the badge, a long beep will sound and the message 'scanning failed' will show.

NOTE: The reader should decode the badge within 1 sec - moving the reader closer to the badge helps in cases when it is not decoding.



Hold reader within 3 inches from badge

Viewing Lead Details

If you have just scanned a lead, a portion of the information stored will appear on the screen. To see all of the lead information:

1. Use the thumbwheel to select the lead you wish to expand.
2. Click the thumbwheel to expand the lead. The thumbwheel can now be used to scroll up and down through the lead.
3. Click the thumbwheel again to return to regular operation.

Entering Qualifiers

To enter followup codes or qualifiers:

1. Press the button labelled 'Qualify'. A new screen will appear showing the followup codes programmed in the unit.
2. Using the thumbwheel, scroll to the qualifier you wish to add and click the thumbwheel. A small checkmark will appear beside it.
3. Enter as many codes as required, then press 'Qualify' to return to normal operation.